

DON'T PLAY – WORK WITH PRECISION

weko

TISSUE LOTIONIZING

YOUR UNIQUE SELLING POINT WITH WEKO!

Customized tissue products!

Create your own and unique hanky, toilet paper, wipe, napkin or facial tissue and raise your margin, quality and company attraction.

Due to the application of water based additives like softener, lotion, balm with vitamins, fragrances, natural extracts etc. you can ensure your market position easily and step into the market of high value customized products. Diversify your product range and be unique!

Improve existing process quality!

Cut your costs and improve your existing processes of lotionizing, bonding, printing and embossing by upgrading your Rewinder or converting lines with WEKO-Fluid-Application system.

Easy. Exact. Repeatable!

Preparing the WEKO Application system only needs setting the target application amount per m² and a push on the start button on our touch panel.



SOFT LOTION



FRAGRANCE



ANTIMICROBIAL



PLY BONDING



RAISE PRINT QUALITY



WEKO-FLUID-APPLICATION-SYSTEM (WFA)

weko

Why settle for anything less than for the No. 1?

With the WEKO rotor application system you have a system that convinces with exact, even and uniform liquid application and leaves nothing to be desired. Your process is perfectly repeatable realizing a stable quality for every production lot.



Advantages of the non-contact application:

- Your USP with lotionizing
- Expand your product range
- Non-contact application
- Reproducibility of the application amount thanks to controlled and exact setting
- Automatic speed compensation
- Easy operation and access

Depending on your needs, single side or both sided application, you will find a suitable WEKO solution.

Different supply units are offered and will meet the demands of your production.

Even and exact application with reproducible quality

The fluid is supplied to fast rotating rotor discs and distributed by the centrifugal forces. This generates a uniform flow of ultra-fine micro-droplets.

Special designed windows creating precisely spraying fans for each rotor which overlap each other and lead to an even liquid application over the complete material web.

The contact-free application provides a constant flow of liquor and so reproducible results combined with gentle treatment of your tissue.

A frequency controlled pump spends 100% speed compensation and an automatic shutter helps to stay in standby mode if your machine will shut down for a moment or is preparing the correct process condition.

Low cost of ownership by minimal maintenance workload

WEKO as the originally founder and worldwide market leader of the rotor application used its more than 65 years experience to design an easy accessible and low maintenance application system - **WEKO-SIGMA** and **WEKO-ProTec** rotor carriers.

The compact design enables easy access and the possibility for retrofitting on existing machines with less space is possible.

